



Temprel's **six-piece depth punch tool** set provides assurance that the thermocouples in the brake pad material are set to the appropriate depth. Correct use involves drilling a pilot hole into the test hardware and pressing the capped end of the thermocouple into place with the seating tool.

Part # TIBTCDP-SET

(Please Contact Temprel for Custom Sizes)

0.5mm

1mm

1.5mm

2mm

2.5mm

Need Help Placing an Order or Have Questions? Call (800) 582-5098

www.temprel.com





Phone: (800) 582-5098 Fax: (231) 582-9491